



## Crane Safe Load Indicator

### PROVIDED PARAMETERS:-

Actual Load

Boom Length

Over Load Alert

(Visual, Audible, Physical Cut Off)

Safe Load

Selected Falls

A2B Alert

(Visual, Audible, Physical Cut Off)

Angle/Radius

Selected Mode

Unsafe Condition Alert

(Visual, Audible, Physical Cut Off)

Percentage Graph